	tum Timber Finishes uct Data Sheet		EVENENCE AND	
Description:	GREY TIMBER	TIMBER BRIGHTENER – CLEANS AND BRIGHTENS WEATHERED AND GREY TIMBER AND ASSISTS IN OPENING THE TIMBER, ALLOWING PENETRATION OF THE NEW COATING.		
How to Apply:	section should be be applied to coo prior to removal. Remove surface d Shake Dex Prep cleaning, one pr discolouration a s Quantum Dex Pr dyes. Wet the surface to Apply mixture g thoroughly. Leave mixture on Rinse off exterior high pressure wat	cleaned at the same time. For l surfaces out of direct sunlig int by sweeping or hosing. thoroughly and mix in a part timber cleaner to five tronger or undiluted solution ep may not remove old deep to be cleaned. enerously with a scouring timber for $10 - 15$ minutes. surfaces thoroughly using m	be avoided and where possible a complete or best results Quantum Dex Prep should ght to avoid cleaner drying on the timber plastic container or bucket For general e parts water. For severe staining or or repeat application may be necessary. o seated fungal stains and timber marking or scrubbing brush and scrub timber maximum pressure from a garden hose. A or large areas or badly discoloured timber. e and water.	
Warning:	discolouration u pH. Allow to dry for	Failure to thoroughly remove the cleaning solution residue may result in timber discolouration under clear finishes or early failure of the coating due to changed pH. Allow to dry for 2 to 3 days before painting or staining with oil based paints. Water based paints may be applied as soon as the timber is dry.		
Coverage:	6 – 8m ² per litre v	$6 - 8m^2$ per litre when diluted.		
Precaution:	-	Dex Prep is mildly acidic, avoid contact with painted metal surfaces n. Rinse off thoroughly if contact occurs.		
Safety Data:	Wear rubber glov	Wear rubber gloves and safety glasses when applying Quantum Timber Cleaner.		
First Aid:	POISON – AVOID CONTACT WITH SKIN AND EYES If poisoning occurs contact a doctor or Poisons Information Center. If swallowed do not induce vomiting give a glass of water. If skin contact occurs remove contaminated clothing and wash skin thoroughly. If eye contact occurs flush eye with water for 15 minutes.			
Ph: 03 9776 8831	Fax: 03 9782 4417	Freecall: 1800 053 018	<u>quantum@qtf.com.au</u>	